

Fissler

STAINLESS STEEL CLEANSER



Removes grease and burned-on food gently and without scratching. A new shine for stainless-steel cookware using natural polishing minerals.

- Strong cleaning power
- Economical in use
- Phosphate- and formaldehyde-free

Calculation of the minimum filling quantity

density (g/cm ³)	1.34	1.30
volume (ml)	250	250
weight product (g)	335	325
weight bottle (g) max.	32	32
total (g)	367	357
weight closure (g)	4.8	4,8
total (g)	371.8	361.8

Calculation of the minimum filling quantity with maximum minus deviation Japan (2%)

density (g/cm ³)	1.34	1.30
volume (ml)	245	245
weight product (g)	328.3	318.5
weight bottle (g) max.	32	32
total (g)	360.3	350.5
weight closure (g)	4,8	4,8
total (g)	365.1	355.3

HOW TO USE:

Shake the bottle briefly. Squirt a little of the cleanser onto a damp cloth, rub it onto the surface to be cleaned, and finally rinse it off. In the case of stubborn dirt, apply the cleanser directly, wait a little while, and then rinse.

INGREDIENTS:

< 5% anionic surfactants, non-ionic surfactants; contains perfume, limonene, citral, preservative, benzisothiazolinone.

Further ingredients: Natural mineral polishing agents, suspending agents, colorant.

LABELLING:



Warning

Hazard statement: Causes serious eye irritation.

Precautionary statements: Keep out of reach of children. Wash hands thoroughly after handling. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention. IF SWALLOWED: Call a POISON CENTER/doctor if you feel unwell.

BUDICH INTERNATIONAL GmbH

Dieselstraße 10
D-32120 Hiddenhausen
Fon +49 5223 9970-0
Fax +49 5223 9970-100
info@budich.de
www.budichinternational.de

A company of the BUDICH Group